

Double Sided 16" Cleanroom Flat Mopping System

Efficient cleaning of floor surfaces is critical to the overall cleanliness of the production environment. The Double Sided 16" Mop System replicate the most effective way to clean and disinfect surfaces - WIPING. The cleanroom flat mop Double Sided holders are easy to use, lightweight and maneuverable

for quick and effective cleaning in both large and small production areas. With the 16" double sided mop, you can clean surfaces to achieve a surface coverage comparable to double that of a conventional flat mop system. (Less frequent changes in mop heads creates a savings in the total cost of

operations.) A sturdy and easy to use mop cart with wringer designed to work with Double Sided flat mops completes the line.



Cleanroom Double Sided Flat Mop Holder

The Double Sided Flat Mop holder's unique double sided design allows operators to clean approximately twice the surface area of a conventional flat mop before changing or re-saturating the mop head, improving cleaning efficiency and reducing cleaning time.

- Double the surface coverage of conventional flat mopping systems
- Attachment and removal of the mop covers without bending
- Extremely maneuverable with a 360 degree swiveling head and flat profile-Ideal for cleaning around production equipment
- Edge mounted handle design perfect for cleaning baseboards
- Durable, autoclavable, plastic

Cleanroom Flat Mop Telescoping Handle

- Durable anodized aluminum with polypropylene grip
- Light weight
- Fully autoclavable

Product	Number	Size	Qty Per Cs
Double Sided Mop	BCRDSMOP10	4"x16" (10cm x 40cm)	10
Double Sided Mop Individual	BCRDSMOP1	4"x16" (10cm x 40cm)	1
Telescoping Handle	BCRHANDLE10	35"to 65" (89cm x 165cm)	10
Telescoping Handle Individual	BCRHANDLE1	35"to 65" (89cm x 165cm)	1

Cleanroom Double Sided Flat Mop Wringer, Cart and Buckets

Composition and Technology

- The Cleanroom Flat Mop Cart is made of high quality stainless steel and is fully autoclavable.
- Locking casters provide stability during use.
- Wringer is made of durable plastic, suitable for the one-step wet cleaning process.
- Ergonomically designed handle serves as a rest for the mop handle and makes the cart easy to maneuver in tight production areas
- Two 20 liter polypropylene buckets are color coded blue and red to differentiate between clean and dirty solutions.
- Internal bucket graduations help insure correct mixing of cleaning and disinfecting solutions



Product	Number	Qty Per Cs	Pks/Cs
Stainless Steel Mop Cart with Buckets - 2, 20 Liter Buckets, Blue, Red	BCRMOPCART1	1	1
Double Sided Mop Wringer	BCRDSWRINGER1	1	1

Cleanroom Double Sided Flat Mop Covers

A range of specially designed mop covers and mop wipers are available for use with the Cleanroom Double Sided Flat Mop. The mop covers, available in both disposable nonwoven and re-laundryable foam/polyester knit composite, allow the mop head to conform to the surface being cleaned, and ensures thorough particle and contaminant removal even on uneven surfaces. The Cleanroom Double Sided Flat Mop system is a reliable and efficient solution for all surfaces. Operators can complete the wet and dry wiping process in just one operation.



Nonwoven Cover Composition and Advantages

- 68 gsm polyester/cellulose outer cover
- 100% rayon nonwoven inner layers provide superior absorbency
- Designed for the capture and removal of contaminants during the cleaning process
- High tear strength
- Each Cover is individually wrapped to preserve cleanliness
- Autoclavable and compatible with gamma and ETO sterilization

Foam Cover Composition and Advantages

- Abrasion resistant polyester knit clean room fabric laminated to absorbent polyurethane foam
- Laser cut to minimize fiber and particle release
- 10 mm thickness provides cushioned surface for optimum conformance to uneven floors.
- High absorbency capacity
- Compatible with a wide range of chemicals, disinfectants and cleaners
- Autoclavable and compatible with gamma and ETO sterilization



Order Information Double Sided Flat Mop Nonwoven Covers

Product	Number	Size	Shts/Pk	Pks/Cs	Style
Double Sided Flat Mop Nonwoven Cover	FMC5NW24	10x17" (25x43cm)	4	24	Stacked

Order Information Double Sided Flat Mop Foam Wipers

Product	Number	Size	Shts/Pk	Pks/Cs	Style
Double Sided Flat Mop Foam Cover	FMC7LF20	10x17" (25x43cm)	4	20	Stacked